

PRODUCT-DETAILS

E 92/32s

E 92/32s Fuse switch disconnecter



Información General

Extended Product Type	E 92/32s
Product ID	2CSM251493R1801
EAN	8012542514930
Catalog Description	E 92/32s Fuse switch disconnecter
Long Description	E 92/32S is a fuseholder for overcurrent and short circuit protection. With blown fuse indicator.

Clasificación

EAN	8012542514930
Minimum Order Quantity	1 piece
Customs Tariff Number	85361010

Dimensiones

Product Net Width	0.035 m
Product Net Height	0.085 m
Product Net Depth / Length	0.064 m
Product Net Weight	0.133 kg

Información de Embalaje

Package Level 1 Units	3 piece
Package Level 1 Width	0.105 m
Package Level 1 Height	0.085 m
Package Level 1 Depth / Length	0.064 m
Package Level 1 Gross Weight	0.369 kg
Package Level 1 EAN	8012542514947

Ambiente

RoHS Status	Following EU Directive 2011/65/EU
-------------	-----------------------------------

Información Adicional

Degree of Protection	IP20
Dimensions	1 module
Fuse Size	10x38 mm
Mounting Type	DIN rail
Number of Poles	2
Number of Protected Poles	2
Options Provided	With LED
Power Loss	at Rated Operating Conditions per Pole 3 W
Product Main Type	E 90
Product Name	Fuse switch disconnecter
Rated Current (I_n)	32 A
Rated Frequency (f)	50...60 Hz
Rated Voltage (U_r)	690 V
Rated Operational Voltage	690 V AC
RoHS Date	41640
Voltage Range	690 V AC

Certificados y Declaraciones (Número de Documento)

Data Sheet, Technical Information	2CSC444002B0204
Declaration of Conformity - CE	2CSC444002D2701
Environmental Information	See RoHS Information
Instructions and Manuals	on the product body
RoHS Information	2CSC444011K2701

Clasificaciones

ETIM 4	EC000036 - Miniature fuse holder
ETIM 5	EC000036 - Miniature fuse holder
ETIM 6	EC002705 - Holder for cylindrical fuse
ETIM 7	EC002705 - Holder for cylindrical fuse
Object Classification Code	F
WEEE Category	5. Small Equipment (No External Dimension More Than 50 cm)

Categorías

Productos y sistemas de baja tensión → Aparatos modulares de instalación → Protection and Safety devices → Cylindrical Fuse Holders and Fuse Switch Disconnectors

